

Installation guide for mounting the frame cap.

Thank you to have chosen our products.

The assembly of our frame caps is very simple:

Please don't grease the O-ring!

With the help of a 5mm allen key please tighten the cap lightly and push it in the frame opening. Now tighten the cap completely with the allen key to stretch the O-ring and give the cap a tightly fixation.

- For this it can be necessary to hold the cap against turning during mounting.

Attention!

Please check the cap for a tightly fixation after some miles of riding.

From time to time please repeat this procedure.

Your MPL - Team